

2013 Esri International User Conference

July 8–12, 2013 | San Diego, California



Restoring the Chesapeake Bay with ArcGIS

Tools for Planning Stormwater Treatment

**Thomas Williams, EIT, LEED AP
AMEC Environment & Infrastructure**

The Chesapeake Bay

- Largest Estuary in the US
- Drains over 64,000 mi²
 - 6 States, plus Washington, DC
- 2009 Executive Order:
 - Declared the Bay a National Treasure
 - Called for a renewed effort to restore and protect the Bay
 - Paved the way for the Chesapeake Bay TMDL



The Chesapeake Bay TMDL



Image Credit: 1

- What is a TMDL?
 - Total Maximum Daily Load
 - EPA-established “pollution diet.”
 - Maximum amount of pollution a water body can receive and still remain healthy.
- The Chesapeake Bay TMDL focuses on three pollutants:
 - Nitrogen
 - Phosphorus
 - Sediment

Urban Stormwater in the Bay Watershed

- Urban stormwater pollution is a major aspect of the Chesapeake Bay TMDL.
- The Bay TMDL is affecting Municipal Separate Storm Sewer System (MS4) operators throughout the Bay Watershed.
- There are many existing tools for stormwater planning, but most are non-spatial.
- **How can we use GIS to...**
 - evaluate stormwater treatment options?
 - track TMDL compliance?
 - make watershed planning easier?



Image Credit: 2




ALERT



- AMEC developed a set of Python tools for ArcGIS, called **ALERT**
 - *AMEC Load Estimation and Reduction Tracking*
- Initially designed around Virginia's draft regulations to implement the Chesapeake Bay TMDL.
- ALERT framework has since been updated and expanded to apply outside of Virginia and the Chesapeake Bay.
- **Built to help communities:**
 - **plan stormwater projects**
 - **quickly evaluate different scenarios**
 - **estimate the cost of compliance**

ALERT Process Diagram




ALERT Process: Calculate Baseline Loads



Landuse Data

- Polygon layer attributed with pollutant loading and runoff information.

- either
- lbs/ac/yr (Loading Rates)
 - mg/L (Event Mean Concentrations)



Baseline Loads

- Total annual pollutant loads (lbs/yr) are calculated.
- Simple Method calculations consider:
 - Impervious area
 - Runoff coefficients
 - Annual precipitation

ALERT Process: Develop Project Database



- Treatment area polygons
- Pollutant removal and runoff reduction efficiencies
- Other relevant information

Water Quality Projects:



Pond Retrofit, 65 acres
Nitrogen Efficiency: 15%
Runoff Reduction: 0%
Cost: \$275,000



Bioretention, 5 acres
Nitrogen Efficiency: 45%
Runoff Reduction: 20%
Cost: \$110,000




Redevelopment, 10 acres
Nitrogen Efficiency: 50%
Runoff Reduction: 10%
Cost: Undetermined

etc...

Stormwater BMPs

Landuse Changes

ALERT Process: Calculate Load Reductions



ALERT Process: Calculate Load Reductions



Baseline Loads


ALERT Process: Calculate Load Reductions



Treatment Area

Reduced Loads

ALERT Process: Non-Spatial Analysis



- Results from GIS analysis can feed into a non-spatial component.
- Non-spatial ALERT tools are used to roughly estimate the remaining effort needed to meet water quality goals.
 - Project needs (acres of treatment)
 - Capital and annual maintenance costs
- Total area of required additional treatment is back-calculated based on pollutant reduction targets.


ALERT Process: Non-Spatial Analysis

1. Project Mix	% by Area
Bioretention	10%
Filtration	10%
New Ponds	30%
Pond Retrofits	50%

2. Target Pollutant	Phosphorus
---------------------	------------

3. Results	
Treatment Area	145 acres
Initial Cost	\$3.5 m
Annual Maint.	\$81,000

Pollutant Loads (lbs/yr)



Results are used to guide further GIS analysis.



More Information:

Thomas Williams, EIT, LEED AP
Water Resources Engineer
AMEC Environment & Infrastructure
thomas.williams@amec.com

Image Credits

1. <http://www.flickr.com/photos/particlem/3733639670/sizes/o/in/photostream/>
2. <http://www.flickr.com/photos/thirteenofclubs/3383558429/sizes/o/in/photostream>

